

FLOOR PLAN

SCALE 1:100 ON A3

Isolation joints shall be placed at all connections between the slab and the walls and also between the slabs of different casts. Transversed sawn-tied joints shall be cut at the positions shown

on the drawing.

Initial sawcut shall be 3 mm wide at a depth of d/4.

Top section of the sawcut shall be reamed to a minimum width of 10 mm and depth of 0.5 * d/4.

Section of joints that shall be sealed with sealant must be cleaned from all loose material and dust before sealant is placed.

SEALANT

Field moulded sealant shall be used to form the sealant for the joints. Thermosetting, chemically sealant shall be used for all joints.

NO.	SPECIAL NOTES:	JPJ KOCH (CHIEF ENGINEER) DECEMBER 2020 (DATE APPROVED)	DEPARTMENT OF RURAL DEVELOPMENT AND AGRARIAN REFORM PROVINCE OF THE EASTERN CAPE ENGINEERING SERVICES PRIVATE BAG X015 DOHNE ADI STUTTERHEIM 4930	SHEARING SHED	SCALE NTS	INDEX NO. SCMM00/24/02
				FLOOR PLAN	A3 ORIGINAL	PLAN NO. SHEET 2 OF 8