



- Generic standard multi-purpose shed design. To be adopted to site specific conditions.
- Look specifically at the slope of the terrain, and the orientation of the building.
- The height of the foundation walls must be adopted.
- It might be needed to add ramps/steps to doors and sliding doors.
- The dimensions of the ramp at the sliding door, will have to be adopted to the terrain.
- It might even be necessary to change the size of the building, depending on specific needs.

**Department Of Rural
Development
& Agrarian Reform**

ENGINEERING SERVICES - CHRIS HANI DISTRICT

Private bag X7187
Queenstown
5320

[illegible]